

Ultrasave's Manitoba Hydro Approval list

CFL HARD-WIRED BALLASTS									
Manufacturer	Model Number	Category	Voltage	Input Power	Lamp	Min Temp	Light Output	Case	Type
Ultrasave	UR242120M-SL	LH	120	84	2X42W	20	100%	p	p
Ultrasave	UR242120M-SL	LH	277	64	2X32W	20	100%	p	p
Ultrasave	UR242120M-SL	LH	120	64	2X32W	20	100%	p	p
Ultrasave	UR242120M-SL	SH	277	45	1X42W	20	102%	p	p
Ultrasave	UR242120M-SL	SH	120	45	1X42W	20	102%	p	p
Ultrasave	UR242120M-SL	LH	277	84	2X42W	20	100%	p	p
Ultrasave	UR242347M-SL	LH	277	84	2X42W	20	100%	p	p
Ultrasave	UR242347M-SL	LH	277	64	2X32W	20	100%	p	p
Ultrasave	UR242347M-SL	SH	347	45	1X42W	20	102%	p	p
Ultrasave	UR242347M-SL	SH	277	45	1X42W	20	102%	p	p
Ultrasave	UR242347M-SL	LH	347	84	2X42W	20	100%	p	p
Ultrasave	UR226120M-SL	LH	120	54	2X26W	20	98%	p	p
Ultrasave	UR226120M-SL	LH	277	54	2X26W	20	98%	p	p
Ultrasave	UR226120M-SL	LH	277	34	1X32W	20	100%	p	p
Ultrasave	UR226120M-SL	LH	277	44	1X42W	20	100%	p	p
Ultrasave	UR226120M-SL	LH	120	44	1X42W	20	100%	p	p
Ultrasave	UR226120M-SL	LH	120	34	1X32W	20	100%	p	p
Ultrasave	UR226120M-SL	LH	120	28	1X26W	20	102%	p	p
Ultrasave	UR226120MHT-SL	LH	120	54	2X26W	20	NT	p	p
Ultrasave	UR226120MHT-SL	LH	120	28	1X26W	20	NT	p	p
Ultrasave	UR226347M-SL	LH	347	28	1X26W	20	102%	p	p
Ultrasave	UR226347M-SL	LH	347	34	1X32W	20	100%	p	p
Ultrasave	UR226347M-SL	LH	347	44	1X42W	20	100%	p	p
Ultrasave	UR226347M-SL	LH	347	54	2X26W	20	98%	p	p
Ultrasave	UR218120M-SL	LH	120	29	2X13W	20	120%	p	p
Ultrasave	UR218120M-SL	LH	277	39	2X18W	20	98%	p	p
Ultrasave	UR218120M-SL	LH	277	29	2X13W	20	120%	p	p
Ultrasave	UR218120M-SL	LH	120	19	1X18W	20	102%	p	p
Ultrasave	UR218120M-SL	LH	120	17	1X13W	20	110%	p	p
Ultrasave	UR218120M-SL	LH	120	39	2X18W	20	98%	p	p
Ultrasave	UR218347M-SL	LH	347	29	2X13W	20	120%	p	p
Ultrasave	UR218347M-SL	LH	347	39	2X18W	20	98%	p	p

Type: I = Instant start, R = Rapid start, P = Programmed start
 Category: LH= Low Harmonics, SH = Standard Harmonics
 Case: P =Potted, NP =Not Potted

Ultrasave's Manitoba Hydro Approval list

T5 BALLASTS STANDARD						
Manufacturer	Model Number	Category	Voltage	Input Power	Approx Lamp Length	Type
Ultrasave	ER221120MHT	LH	120V	34	2x2'	p
Ultrasave	ER221120MHT	LH	120V	25	1x3'	p
Ultrasave	ER221120MHT	LH	120V	50	2x3'	p
Ultrasave	ER221347M	LH	347V	50	2x3'	p
Ultrasave	ER221347M	LH	347V	34	2x2'	p
Ultrasave	ER221347M	LH	347V	18	1x2'	p
Ultrasave	ER235120MHT	LH	120V	60	2x4'	p
Ultrasave	ER235120MHT	LH	120V	80	2x5'	p
Ultrasave	ER235120MHT	LH	120V	30	1x4'	p
Ultrasave	ER235347MHT	LH	347V	60	2x4'	p
Ultrasave	ER235347MHT	LH	347V	80	2x5'	p
Ultrasave	SR 132120	SH	120V	32	1x4'	p

Category: LH= Low Harmonics, SH= Standard Harmonics
Type: I = Instant start, R = Rapid start, P = Programmed start

Ultrasave's Manitoba Hydro Approval list

T5 HO BALLASTS						
Manufacturer	Model Number	Category	Voltage	Input Power	Approx Lamp Length	Type
Ultrasave	ER 224120M	LH	120V	51	2x2'	p
Ultrasave	ER 224120MHT	LH	120V	26	1x2'	p
Ultrasave	ER 224347MHT	LH	277V	51	2x2'	p
Ultrasave	ER 224347MHT	LH	347V	51	2x2'	p
Ultrasave	ER 239120MHT	LH	120V	82	2X3'	p
Ultrasave	ER 239120MHT	LH	120V	46	1X3'	p
Ultrasave	ER 239347M	LH	347V	82	2x3'	p
Ultrasave	ER 239347MHT	LH	347V	82	2x3'	p
Ultrasave	ER 254120MHT	LH	120V	62	1x4'	p
Ultrasave	ER 254120MHT	LH	120V	116	2x4'	p
Ultrasave	ER 254120MHT	LH	277V	116	2x4'	p
Ultrasave	ER 254120MHT-W	LH	120V	62	1x4'	p
Ultrasave	ER 254120MHT-W	LH	120V	116	2x4'	p
Ultrasave	ER 254120MHT-W	LH	277V	116	2x4'	p
Ultrasave	ER 254347HT-W	LH	347V	62	1x4'	p
Ultrasave	ER 254347HT-W	LH	347V	118	2x4'	p
Ultrasave	ER 254347M	LH	347V	114	2x4'	p
Ultrasave	ER 254347MHT	LH	347V	114	2x4'	p
Ultrasave	ER 454120MHT-W	LH	120V	240	4x4'	p
Ultrasave	ER 454120MHT-W	LH	277V	240	4x4'	p
Ultrasave	ER 454120MHT-W	LH	277V	182	3x4'	p
Ultrasave	ER 454120MHT-W	LH	120V	182	3x4'	p
Ultrasave	ER 454120MHT-W	LH	120V	240	4x4'	p
Ultrasave	ER 454120MHT-W	LH	120V	182	3x4'	p
Ultrasave	ER 454120MHT-W	LH	277V	240	4x4'	p
Ultrasave	ER 454120MHT-W	LH	277V	182	3x4'	p
Ultrasave	ER 454347HT-W	LH	347V	240	4x4'	p
Ultrasave	ER 454347HT-W	LH	347V	182	3x4'	p
Ultrasave	PR 180120MHT-P	LH	120V	83	1x5'	R

Category: LH= Low Harmonics, SH= Standard Harmonics
Type: I = Instant start, R = Rapid start, P = Programmed start

Ultrasave's Manitoba Hydro Approval list

T8 BALLASTS STANDARD						
Manufacturer	Model Number	Category	Voltage	Input Power	Length	Type
Ultrasave	GT 232120	Standard	120V	53	2x3'	I
Ultrasave	GT 232120	Standard	120V	58	2x4'	I
Ultrasave	GT 432120	Standard	120V	107	4x3'	I
Ultrasave	GT 432120	Standard	120V	112	4x4'	I
Ultrasave	UT 232120H	Standard	120V	75	2x4'	I
Ultrasave	UT 232120M	Standard	120V	37	1x4'	I
Ultrasave	UT 232120M	Standard	208V	37	1x4'	I
Ultrasave	UT 232120M	Standard	277V	37	1x4'	I
Ultrasave	UT 232120ML	Standard	120	29	2x2'	I
Ultrasave	GT 232347	Standard	347V	51	2x3'	I
Ultrasave	GT 432347	Standard	347V	106	4x3'	I
Ultrasave	GT 432347	Standard	347V	109	4x4'	I
Ultrasave	PR 232347	Standard	347V	40	1x4'	R
Ultrasave	UT 132347	Standard	347V	26	1x3'	I
Ultrasave	UT 232347	Standard	347V	37	1x4'	I
Ultrasave	UT 232347L	Standard	347V	28	2x2'	I
Ultrasave	UT 232347L	Standard	347V	39	2x3'	I
Ultrasave	UT 232347L	Standard	347V	31	1x4'	I
Ultrasave	UT 332347	Standard	347V	64	2x4'	I
Ultrasave	UT 332347	Standard	347V	65	3x3'	I

Type: I = Instant start, R = Rapid start, P = Programmed start

Ultrasave's Manitoba Hydro Approval list

T8 BALLASTS PREMIUM						
Manufacturer	Model Number	Category	Voltage	Input Power	Length	Type
Ultrasave	UT 332120	Premium	120V	50	2x3'	I
Ultrasave	UT 332120M	Premium	120V	64	2x4'	I
Ultrasave	UT 332120M	Premium	120V	83	3x4'	I
Ultrasave	UT 332120MH	Premium	120V	110	3x4'	I
Ultrasave	UT 332120ML	Premium	120V	76	3x4'	I
Ultrasave	UT 332120ML	Premium	120V	58	2x4'	I
Ultrasave	UT 432120	Premium	120V	93	3x4'	I
Ultrasave	UT 432120	Premium	120V	89	4x3'	I
Ultrasave	UT 432120	Premium	120V	112	4x4'	I
Ultrasave	UT 432120L	Premium	120V	93	4x4'	I
Ultrasave	UT 432120L	Premium	120V	73	4x3'	I
Ultrasave	UT 432120L	Premium	120V	78	3x4'	I
Ultrasave	UT 432120M	Premium	120V	112	4x4'	I
Ultrasave	UT 432120M	Premium	277V	112	4x4'	I
Ultrasave	UT 432277L	Premium	277V	99	4x4'	I
Ultrasave	UT 432277L	Premium	277V	81	3x4'	I
Ultrasave	ET432120M	Premium	120V	108	4x4'	I
Ultrasave	ET432120M	Premium	120V	92	3x4'	I
Ultrasave	ET232120M	Premium	120V	57	2x4'	I
Ultrasave	ET232120M	Premium	120V	36	1x4'	I

Type: I = Instant start, R = Rapid start, P = Programmed start

Ultrasave's Manitoba Hydro Approval list

T8 BALLASTS PREMIUM						
Manufacturer	Model Number	Category	Voltage	Input Power Power	Length	Type
Ultrasave	PR 232120	Premium	120V	32	1x3'	R
Ultrasave	PR 232120	Premium	120V	52	2x3'	R
Ultrasave	PR 232120	Premium	120V	40	1x4'	R
Ultrasave	PR 332120	Premium	120V	61	3x2'	R
Ultrasave	PR 332120	Premium	120V	77	3x3'	R
Ultrasave	PR 332120	Premium	120V	91	3x4'	R
Ultrasave	PR 432120	Premium	120V	121	4x4'	R
Ultrasave	SR 132120	Premium	120V	24	1x3'	p
Ultrasave	SR 232120	Premium	120V	50	2x3'	p
Ultrasave	SR 232120	Premium	120V	55	2x4'	p
Ultrasave	ST 132120	Premium	120V	24	2x3'	I
Ultrasave	ST 232120	Premium	120V	58	2x4'	I
Ultrasave	UT132120	Premium	120V	31	1x4'	I
Ultrasave	UT 132120L	Premium	120V	27	1x4'	I
Ultrasave	UT 132120L	Premium	120V	17	1x2'	I
Ultrasave	UT 132120M	Premium	120V	31	1x4'	I
Ultrasave	SR 132120	Premium	120V	30	1x4'	p
Ultrasave	UT 232120	Premium	120V	58	2x4'	I
Ultrasave	UT 232120M	Premium	120V	48	2x3'	I
Ultrasave	UT 232120M	Premium	120V	58	2x4'	I
Ultrasave	UT 232120M	Premium	208V	58	2x4'	I
Ultrasave	UT 232120M	Premium	277V	58	2x4'	I
Ultrasave	UT 232120MH	Premium	120V	75	2x4'	I
Ultrasave	UT 232120MH	Premium	277V	58	2x3'	I
Ultrasave	UT 232120MH	Premium	120V	58	2x3'	I
Ultrasave	UT 232120MH	Premium	277V	75	2x4'	I
Ultrasave	UT 232120ML	Premium	120	50	2x4'	I
Ultrasave	UT 232120ML	Premium	120	31	1x4'	I
Ultrasave	UT 232120ML	Premium	120	38	2x3'	I
Ultrasave	UT 260120	Premium	120V	110	2x8'	I
Ultrasave	UT 260120M	Premium	120V	69	1x8'	I
Ultrasave	UT 260120M	Premium	120V	110	2x8'	I
Ultrasave	UT 332120	Premium	120V	50	2x3'	I
Ultrasave	UT 332120	Premium	120V	64	2x4'	I
Ultrasave	UT 332120	Premium	120V	64	3x3'	I
Ultrasave	UT 332120	Premium	120V	83	3x4'	I

Type: I = Instant start, R = Rapid start, P = Programmed start

Ultrasave's Manitoba Hydro Approval list

T8 BALLASTS PREMIUM						
Manufacturer	Model Number	Category	Voltage	Input Power	Length	Type
Ultrasave	PR 132347	Premium	347V	35	1x4'	R
Ultrasave	PR 232347	Premium	347V	52	2x3'	R
Ultrasave	PR 232347	Premium	347V	64	2x4'	R
Ultrasave	PR 332347	Premium	347V	91	3x4'	R
Ultrasave	PR 332347	Premium	347V	61	3x2'	R
Ultrasave	PR 332347	Premium	347V	77	3x3'	R
Ultrasave	PR 432120ML	Premium	347V	107	4x4'	R
Ultrasave	PR 432347	Premium	347V	121	4x4'	R
Ultrasave	PR 432347L	Premium	347V	104	4x4'	R
Ultrasave	UT 232347	Premium	347V	58	2x4'	I
Ultrasave	UT 232347L	Premium	347V	48	2x4'	I
Ultrasave	UT 232347H	Premium	347V	58	2x3'	I
Ultrasave	UT 260347	Premium	347V	72	1x8'	I
Ultrasave	UT 332347	Premium	347V	83	3x4'	I
Ultrasave	UT 332347L	Premium	347V	60	3x3'	I
Ultrasave	UT 332347L	Premium	347V	58	2x4'	I
Ultrasave	UT 332347L	Premium	347V	78	3x4'	I
Ultrasave	UT 332347L	Premium	347V	45	2x3'	I
Ultrasave	UT 332347H	Premium	347V	110	3x4'	I
Ultrasave	UT 432347	Premium	347V	112	4x4'	I
Ultrasave	UT 432347	Premium	347V	93	3x4'	I
Ultrasave	UT 432347L	Premium	347V	99	4x4'	I
Ultrasave	PR 132120	Premium	120V	28	1x3'	R
Ultrasave	PR 232120	Premium	120V	64	2x4'	R
Ultrasave	PR 232120	Premium	120V	25	1x2'	R
Ultrasave	PR 232120	Premium	120V	38	2x2'	R

Type: I = Instant start, R = Rapid start, P = Programmed start